

SBS-2002 Digital Hydrometer

Cleaning Guide

In order to keep the SBS-2002 Digital Hydrometer clean for accurate readings during use, a few simple steps are required.

- 1) Flush the SBS-2002 with distilled water after each days use, or between periods of measurements.
- 2) Keep the exterior of the unit dry and free of dirt and acid. (wipe exterior of unit with distilled water prior to replacing it in the case).
- 3) Weekly inspect the prism surface for staining, cloudiness, or discoloration. Remove the sample pump by releasing the latch. Inspect Prism for clean shinny surface.
 - a. If prism is cloudy, or discolored first clean with distilled water and towel.
 - b. If cloudiness is still present, use denatured or rubbing alcohol and a (Q-tip) to clean the prism surface
 - c. Rinse with distilled water prior to sampling.

